### **COVID-19 DECLARATION OF EFFECTIVENESS**

The company Premium Factory certifies that the NOCOTECH disinfection system (coupled system of NOCOSPRAY or NOCOMAX devices and NOCOLYSE), by its full spectrum of efficacy (bactericide, fungicide, sporicide and virucide) is also effective on **Covid-19** 

**Covid-19** is part of the Coronavirus family with an RNA envelope. It is similar to SARS, very contagious and highly mutant.

The precautionary methods are the same as in 2002 or 2009: avoid hand contact or sneezing and disinfect surfaces as regularly as possible.

**Covid-19** is sensitive to H<sub>2</sub>0<sub>2</sub>, much more reactive to disinfectants than noroviruses, adenoviruses or **polioviruses on** which the NOCOTECH concept gives excellent results (studies available on request).

Because the precautionary principle must always prevail, we recommend regular treatment of all public places or gathering places. Thus, the risk of contamination from surfaces will be minimized.

If a case of Covid-19 is detected, all potentially infected surfaces should be treated.

### **RECOMMENDED TREATMENT**

EQUIPMENT: NOCOSPRAY or NOCOMAX (for large volumes)

**PRODUCT:** NOCOLYSE + or NOCOLYSE FOOD (depending on specific needs)

DOSE: 5 ml / m<sup>3</sup>. Program the device on the volume of the part to be treated by multiplying it by 5

**DURATION OF TREATMENT:** Diffusion + 2 hours (Before using the room, allow 2 hours after diffusion)

### **PART PROCESSING GUIDE**

ROOM VOLUME (m <sup>3</sup> )	10	20	30	40	50	100	150	200
DIFFUSION TIME (min: sec)	03:00	06:00	09:00	12:00	15:00	30:00	45:00	60:00
CONSUMPTION (ml)	50	100	150	200	250	500	750	1000

### **USE OF THE DEVICE**

Connect the Nocospray 2 power cable Put the switch on I

NOCOTECH

Select the volume to be processed by sliding your finger on the light part of the keyboard. In standard mode, the volume selected by default is 10m<sup>3</sup>, the selection range is between 10m<sup>3</sup> and 1000m<sup>3</sup>



The level is progressive: if two LEDs are lit, the intermediate value is selected.

For example, if LEDs 10 and 20 are on, the volume selected is 15 m3

To start, press the button in the center of the keyboard (long press).



A beep sounds for 15 seconds before the machine starts operating. Leave the room before the end of 15 seconds. At the end of the broadcast, a beep sounds. The device stops automatically.





Use biocidal products with care, Before any use, read the label and the information concerning the product,

# **OUR NOCOTECH PRODUCTS**





#### NOCOSPRAY: OUR LIGHTWEIGHT AND PORTABLE **DIFFUSION DEVICE**

Exists in wall fixing and in crossing of partition.



Exists in wall fixing.



# DETERGENT **PRODUCTS**

### BIOSWEEPS

Natural and non-ionic degreaser.

### BIOSWEEP Z

Natural and non-ionic detergent ready for use containing enzymes.

### BIOMOP


Natural and non-ionic concentrated degreasing detergent for floors.



# **INSECTICIDE PRODUCTS**



OXYPY+



# **DISINFECTANT PRODUCTS**

### NOCOLYSE

Ready-to-use bio-disinfectant containing 6% hydrogen peroxide and 17 ppm silver.

## NOCOLYSE ONE SHOT

Ready-to-use bio-disinfectant containing 12% hydrogen peroxide and 17 ppm silver.

## NOCOLYSE FOOD

Ready-to-use bio-disinfectant containing 7.9% hydrogen peroxide, without silver. Suitable for treatment food contact surfaces.

### **QUALITY MONITORING KIT**

Nocobox is a culture box containing nutrients that promote bacterial growth and reveal the presence of bacteria on surfaces. Nocotest controls the uniform diffusion of the product.

## ACCESSORIES

### **REMOTE CONTROL**

Allows activation of the diffusion device from outside the room. Only works with Nocospray.



NOCO TECH®

### **BULKHEAD SYSTEM KIT**

Bulkhead crossing system allowing disinfection of a room without entering it. Only works with Nocospray.



#### PROGRAMMER

Allows automatic activation of the diffusion (various programming possible). Works with Nocospray and Nocomax Easy.



### **DOUBLE NOZZLE**



Allows two-way diffusion, well suited to long and narrow spaces such as corridors. Only works with Nocospray.





Use biocidal products with care, Before any use, read the label and the information concerning the product,



