



- **OXYDOR** is a deodorant product effective on odors of organic or bacterial origin (urine, tobacco, trash, animals, industries, ...).
- **OXYDOR** is a solution based on essential oils, ready to use, designed to be used with the **NOCOTECH** range of diffusion devices or in local applications with a sprayer.

## REFERENCES AND PACKAGING

Reference	Packaging
PSALOR1	1 Liter

## COMPOSITION

Essential oils.

## CONSERVATION

- Keep the product in the original packaging, vertically and in a cool, well-ventilated place.
- Validity : In the original closed packaging: 2 years from the date of manufacture.  
Once uncapped: 2 months from the opening date.

PREMIUM FACTORY SAS

1 Route Neuve  
71710 Montcenis

EMail: [contact@premiumfactory.eu](mailto:contact@premiumfactory.eu)

Tel: +33 805 691 327

[www.premiumsanitary.eu](http://www.premiumsanitary.eu)



## PRECAUTIONS FOR USE

- Consult the product safety data sheet, available on request by email: [contact@premiumfactory.eu](mailto:contact@premiumfactory.eu)

## MANUAL

### Protocol for occasional or curative use

- Follow the instructions for using the NOCOTECH<sup>®</sup> range diffusion device (see instructions and quickstart document).
- Screw the 1L bottle onto the NOCOSPRAY<sup>®</sup> dispenser or the 20L canister into the NOCOMAX<sup>®</sup> dispenser
- Adjust the device to the volume (V) of the room.  
For example, a room of 20m<sup>2</sup> with a height of around 2.50m will make a volume of  $20 \times 2.50\text{m} = 50\text{m}^3$ .  
The device will then have to be set to 50m<sup>3</sup>.
- After the end of the diffusion, remove the bottle from the device and close it.
- The treatment should be repeated as often as necessary.

PREMIUM FACTORY SAS

1 Route Neuve  
71710 Montceau

EMail: [contact@premiumfactory.eu](mailto:contact@premiumfactory.eu)

Tel: +33 805 691 327

[www.premiumsanitary.eu](http://www.premiumsanitary.eu)

